













# INSTALLATION MANUAL

**LiGHT 4u****BALDR S.**

AC220-240V | 50/60Hz | IP20 | Die cast



Do not operate with power supply connected.

<p><b>1</b></p> 	<p><b>2</b></p>  <p>Ø115</p> <p>Open a 115mm diameter hole in the ceiling.</p>	<p><b>3</b></p>  <p>Connect the power supply(AC220-240V).</p>
<p><b>4</b></p>  <p>Pull on the sketch clamp along the arrow direction.</p>	<p><b>5</b></p>  <p>Clip upward and place the product in the hole in the ceiling.</p>	<p><b>6</b></p>  <p>The installation is complete.</p>
<p><b>7</b></p>  <p>Switch on the power, lighting.</p>	<p><b>8</b></p> 	

**Warnings:**

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.